



For Operable / Awning windows, drywall should return back to the window frame with a corner bead at the edge. We provide enough 4" MDF trim to serve as floor base and door casing, not as a window casing. **PRIOR EXPERIENCE IS RECOMMENDED.**

For Fixed Glass Windows / Lites:



- Install **fiberglass batt insulation**. Wear protective glasses and mask to avoid dust.

- Install nailer boards in all corners. **Any scrap 2x lumber will work**. See photo 1 - Circled in orange.

- There should be drywall in between the wood window stops where necessary, but **no drywall on window returns themselves**. The edge of window stop should be **flush with the face of drywall**. Install corner bead.

- Tape and apply skim coat including window returns. **In the window returns, skim coat will be directly on the wood**. See Photo 2.



- Install drywall as **ceiling of shed**. Beetle Kill planks included if purchased with kit.

- Use the vendor's instructions to install vapor barrier and **laminate flooring**. Then install **baseboard along the interior perimeter of building**. If desired, **case around door**. We do not supply casing for windows.

* For operable/awning windows, use drywall returns with corner bead to cover the gap between window frame and rough opening/framing. See photo 3.

