



INSTALLATION GUIDE

SIGNATURE SERIES SHEDS

BLOCK SIDING INSTALLATION




Fig 1a:

INSTALL BOTTOM TRIM PROFILE 'C' (DRIP EDGE):

- STEP 1:
MEASURE THE BUILDING WALL AND CUT THE TRIM TO FIT. DRIP EDGE WILL MEET UP AT BUILDING CORNERS. ALL CORNER CUTS MUST BE 45° MITRE CUTS.
- STEP 2:
USING A PNEUMATIC BRAD NAILER, WITH 3/4" GALVANIZED BRAD NAILS, SECURE THE DRIP EDGE TO THE SHED. NAIL ~12" ON CENTER ALONG VERTICAL LEG OF DRIP EDGE. USE A CARPENTER'S LEVEL TO ENSURE DRIP EDGE REMAINS LEVEL DURING INSTALLATION.
- *PLAN SPLICES, IF MULTIPLE PIECES ARE USED, IN LEAST VISIBLE LOCATIONS (AWAY FROM DOORS AND WINDOWS)

ALIGN KICK-OUT ANGLE WITH
BOTTOM OF WALL SHEATHING




Fig 1b:

DOOR OPENING

SQUARE CUT DRIP EDGE AT EACH SIDE
OF DOOR OPENING

DRIP EDGE MEETS UP AT CORNERS




Fig 2a:

INSTALL TRIM PROFILE 'E' (2" FLAT METAL):

- REFERENCE PROJECT INSTALLATION DRAWINGS FOR SIDING DIAGRAMS AND DIMENSIONS.

- STEP 1:
USE A TAPE MEASURE AND CHALK LINE TO SNAP HORIZONTAL AND VERTICAL CENTERLINES OF TRIM PROFILE 'E'. THE CENTERLINES WILL BE LOCATED AT THE REVEALS IN-BETWEEN THE BLOCK SIDING PANELS.

- *HORIZONTAL CENTERLINES WILL BE THE SAME ON ALL SIDES.




Fig 2b:

- STEP 2 - INSTALL HORIZONTAL PIECES:
MEASURE THE BUILDING WALL AND CUT THE HORIZONTAL LENGTHS OF TRIM PROFILE 'E'.

- STEP 3:
ALIGN THE CENTERLINE OF THE TRIM WITH THE CENTERLINES SNAPPED DURING STEP 1.

USING A PNEUMATIC BRAD NAILER, WITH 3/4" LONG GALVANIZED BRAD NAILS, SECURE THE TRIM TO THE SHED WALL. ENSURE THE METAL IS TIGHT BY WORKING FROM ONE END TO THE OTHER.

LOCATE ALL NAILS WHERE THEY WILL BE CONCEALED BY BLOCK SIDING PANELS (~1/4" IN FROM THE EDGE OF THE METAL).




Fig 3a:

- STEP 4:
CUT TO FIT AND INSTALL TRIM PROFILE 'E' ALONG THE TOP OF THE BUILDING WALL. USE NAILING METHOD DESCRIBED IN STEP 3. ALIGN THE TOP OF THE TRIM WITH THE TOP OF THE WALL SHEATHING.
- *RIGHT, LEFT AND BACK WALLS ONLY.




Fig 3b:

- STEP 5 - INSTALL VERTICAL PIECES:
CUT TO FIT AND INSTALL VERTICAL PIECES OF TRIM PROFILE 'E'. VERTICAL TRIM SHOULD OVERLAP HORIZONTAL METAL. USE NAILING METHOD DESCRIBED IN STEP 3.





Fig 4a:

- STEP 6 - INSTALL DOOR TRIM:
CUT TO FIT AND INSTALL TRIM PROFILE 'E' AROUND DOOR OPENING(S). OVERLAP TRIM INTO DOOR OPENING ~1/2" TO COVER GAP BETWEEN DOOR JAMB AND WALL FRAMING. USE NAILING METHOD DESCRIBED IN STEP 3.

TOP HORIZONTAL PIECE MAY NOT BE REQUIRED IF WALL PANEL CLADDING EXTENDS INTO DOOR OPENING.

- *DOOR NOT SHOWN.

Fig 4b:



SHORT SIDE OF METAL HAS ANGLED CUT TO MATCH ROOF SLOPE

INSTALL TRIM PROFILE 'B' (CORNER CAPS):

- STEP 1:
MEASURE EACH CORNER FROM THE TOP OF THE KICK-OUT ON THE DRIP EDGE TO THE TOP OF THE WALL SHEATHING.

- STEP 2:
CUT THE CORNER CAP TO FIT. BE SURE TO CUT THE END THAT DOES NOT HAVE THE ANGLED CUT TO MATCH THE ROOF SLOPE.

- STEP 3:
ADHERE THE CORNER CAP TO THE SHED BY APPLYING SIKAFLEX SEALANT TO THE BACKSIDE OF THE METAL. THE SHORT SIDE WILL BE ON THE SIDE WALLS.

- *DO NOT USE NAILS TO SECURE.

BOTTOM OF CORNER CAP WILL SIT ON TOP OF KICK-OUT ON DRIP EDGE




Fig 5a:

INSTALL BLOCK SIDING PANELS:

- STEP 1:
APPLY LIQUID NAILS TO BACKSIDE OF BLOCK SIDING PANELS (LIQUID NAILS SHOULD NOT SQUEEZE OUT OF EDGES WHEN PANEL IS PRESSED AGAINST THE SHED)




Fig 5b:

- REFERENCE PROJECT INSTALLATION DRAWINGS FOR SIDING DIAGRAMS AND DIMENSIONS. SIDING IS LABELED BY LOCATION.
- STEP 2 - INSTALL BOTTOM ROW:
STARTING AT A BOTTOM CORNER, PLACE THE BLOCK SIDING PANEL AGAINST THE SHED WALL. THE BOTTOM OF THE SIDING WILL SIT ON TOP OF THE KICK-OUT ON THE BASE DRIP EDGE/ BOTTOM OF WALL SHEATHING.

USE A CARPENTER'S LEVEL TO ENSURE PANEL IS LEVEL.

1 1/2" GALVANIZED BRAD NAILS CAN BE USED TO HELP FACILITATE INSTALLATION. FOR BEST RESULTS PLACE NAILS WHERE THERE IS WALL FRAMING.
- STEP 3:
PLACE THE ADJACENT SIDING PANEL USING THE SUPPLIED SPACER BLOCK. THE SPACE BETWEEN THE SIDING PANELS WILL BE 1/2".




Fig 6a:

- STEP 4 - INSTALL PRE-CUT PANELS: WORKING FROM THE BOTTOM UP, INSTALL ALL THE PRE-CUT PANELS. USE METHODS DESCRIBED IN STEPS 1-3.





Fig 6b:

- STEP 5 - TRIM AND INSTALL REMAINING PANELS: MEASURE AND TRIM BLOCK SIDING PANELS LOCATED AT THE TOP OF THE SIDE WALLS AND AROUND WINDOWS.
- USING A CIRCULAR SAW, GUIDE AND FIBER CEMENT BLADE IS RECOMMENDED.
- USE INSTALLATION STEPS DESCRIBED IN STEPS 1-3.

Fig 7a:



- **STEP 6 - INSTALL DECORATIVE SCREWS:**
PRE-CUT SIDING PANELS WILL HAVE PRE-DRILLED SCREW HOLES.

- 3/16" Ø HOLES WILL NEED TO BE DRILLED AT THE CORNERS OF TRIMMED SIDING PANELS. THESE HOLES SHOULD BE LOCATED 1 1/2" IN FROM THE SIDING PANEL EDGES.

- **STEP 7:**
USE A 1/8" Ø DRILL BIT TO DRILL THROUGH ANY METAL TRIM THAT MAY BE PRESENT BEHIND SCREW HOLES.

- **STEP 8:**
USING A PH3 PHILIPS BIT, INSTALL THE SUPPLIED SCREWS AND WASHERS AT THE SIDING PANEL CORNERS.